

40 inch Change: SAAO CCD OFF

As at March 2014 - JC

For SAAO STE3 and STE4 detectors

Warm Room

1. Close all programs and shutdown Imag40.suth

Observing Floor

1. Disconnect CCD/ACQ cable to ACQ Box
2. Disconnect mains power to power supply
3. Disconnect Filter Cables to filter wheels
4. Disconnect Fiber to CCD Merlin (color-to-color)
5. Disconnect CCD Cables to Power Supply
6. Remove Power Supply (Ensure correct one is stored with STE 3 & STE 4 respectively)
7. Remove CCD cryostat
8. Ensure the following remains mounted on the telescope (they are never removed):
 - Acquisition Box
 - XY Slides & Acquisition Camera
 - Filter Box (with correct filter wheels)
 - Pneumatics plugged in