

74 inch Change: SAAO CCD OFF (with/without Focal Reducer)

For SAAO STE3 and STE4 detectors

November 2008

Warm Room

1. Close program and shut pc down.
2. Disconnect keyboard, time, network and CCD controller fiber from the computer
3. Store PC in old warm room

Observing Floor

1. Disconnect fiber from CCD Merlin Crate
 2. Disconnect filter cables from filter wheels
 3. Power down CCD PSU and remove mains cable
 4. Disconnect CCD cables from PSU
 5. Remove CCD cryostat/shutter/turntable combination from filter box
- OR
6. Remove CCD cryostat/shutter combination from focal reducer
 7. Remove focal reducer from filter box